


ASSEMBLY INSTRUCTION















YUMI NEST OF TABLES





ROWICO

H O M E




Ax1 	Hx12  Ø16/Ø6.5
Bx3 	Ix6  Ø20
Cx1 	Jx1  Ø4
Dx3 	Kx12  Ø4 × 50MM
Ex2 	Lx6  Ø10 × 45
Fx12  M6 × 40MM	Mx2 
Gx12  Ø10.4/Ø6.5	 Ø8 × 30

1



2



3

